


Legend

ENG = Ground To Engine Block
FWL = Ground To Firewall
BLK = Ground To 24 Pin Ground Block
Note: Ground wire gauges are equal to or greater than the corresponding positive lead



Sonex 800
Wiring Diagram

Revised: 12/20/2014